

The North Face® Ladies Ridgewall Soft Shell Vest

Size Chart					
	S	M	L	XL	2XL
Size	4/6	8/10	12/14	16/18	20/22
Bust	33-35	36-38	39-41	42-44	45-48

BUST

Measure under the arm and around the fullest part of the bust with arms down, keeping tape horizontal.